

## INTRODUCTION

This document is a quick reference guide for the most commonly needed spare parts for Crown V-Rack 4x3500HD. For the complete list of parts, assembly drawings, and more, refer to the **V-Rack 4x3500HD SBOM** (Service Bill of Materials), available for download from the Crown Audio Service Portal.

## RACK COMPONENTS

PART NUMBER	TYPE	DESCRIPTION
5070593	4x3500HD Rack	Empty Rack
5141185-00	Door	Plexiglass swing door with hinge
5141186-00	Wheel Plate	Complete wheel dolly assembly
5141188-00	Caster	Single replacement caster

## ELECTRONICS

PART NUMBER	TYPE	DESCRIPTION
5066631-01X	4x3500HD Input Panel	Input Panel
5066633	4x3500HD PD	Power Distribution Panel
5074101	Data Switch	Network Data Switch

## OTHER

PART NUMBER	TYPE	DESCRIPTION
5068381	12V DC PSU	12V DC, 2.1A - 115-230VAC PSU
5068380	5V DC PSU	5V DC, 5A - 115-230VAC PSU